



DREADNOUGHT E T-TYPE SETUP

DREADNOUGHT E

T-TYPE SETUP



PREPARATION

Before the transmission can be installed, the chain length and derailleur must be prepared.

CHAIN LENGTH

See the table to find the recommended chain length for your frame size.

CHAIN LENGTH GUIDE

FRAME SIZE	SETUP KEY	SET UP COG	CHAIN LENGTH	CR. SIZE	MAX CR. SIZE
S1	A	6	122 LINKS	34T	36T
S2	A	6	124 LINKS	34T	36T
S3	A	6	126 LINKS	34T	38T
S4	A	6	128 LINKS	34T	38T

SRAM’s T-Type transmission requires a specified setup procedure based on chain length and derailleur configuration. This setup does away with the need for b-tension adjustments.

For the full Eagle Transmission setup guides, please scan the following QR codes,



Mechanical T-Type
Set Up



AXS T-Type
Set Up

NOTE: SRAM T-Type is only compatible with frames equipped with SRAM’s Universal Derailleur Hanger (UDH) fitment.