

PUSH HC-97

CHARGER 2.0 Rebound Tuning Guide

This guide applies to Charger 2.0 only. (White band on the Red Piston)



Step 1 - Select your Rebound Code based on your rider weight range.

Step 2 - Use a ruler or caliper to identify the shims for the selected Rebound Code.

Step 3 - Lay out the shims in the order defined below on a clean lint-free surface.

Step 4 - Install the shims onto the Rebound Bolt starting with the 13mm shim.

REBOUND CODE	WEIGHT RANGE
STOCK	< 160
RP1	160 - 190
RP2	190 - 220
RP3	220 <

