



HC97

COMPRESSION SYSTEM

Quick Start Guide

Below is a quick start guide for the damper settings of your new HC97 Compression System. Please note that this is intended to be a starting point and that we recommend experimenting with additional settings to find your preferred balance of comfort and control.

All settings are "out" from full closed, meaning that the adjuster should be turned completely clockwise until it stops, and then turned counter-clockwise that amount of clicks. Your specific starting settings will be found underneath your rider weight range in the chart below.

120lbs/54kg - 145lbs/66kg	145lbs/66kg - 170lbs/77kg	170lbs/77kg - 195lbs/88kg	195lbs/88kg - 220lbs/100kg	220lbs/100kg - 240lbs/109kg	240lbs/100kg - 255lbs/116kg
LSC-21 Out HSC-17 Out Reb-11 Out	LSC-21 Out HSC-16 Out Reb-11 Out	LSC-20 Out HSC-15 Out Reb-10 Out	LSC-19 Out HSC-15 Out Reb-10 Out	LSC-17 Out HSC-14 Out Reb-9 Out	LSC-16 Out HSC-14 Out Reb-7 Out